


# **NLFACP**

## **Milk & Beverage Dispensers**

### **Original Instructions**

### **Installation, Operation and Maintenance Manual**

This manual is updated as new information and models are released. Visit our website for the latest manual.



 **Caution**

**Original Document**

Read this instruction before operating this equipment.

## Safety Notices

### ⚠ Warning

Read this manual thoroughly before operating, installing or performing maintenance on the equipment. Failure to follow instructions in this manual can cause property damage, injury or death.

### ⚠ DANGER

Do not install or operate equipment that has been misused, abused, neglected, damaged, or altered/modified from that of original manufactured specifications.

### ⚠ DANGER

All utility connections and fixtures must be maintained in accordance with local and national codes.

### ⚠ DANGER

Use appropriate safety equipment during installation and servicing.

### ⚠ Warning

Do not damage the refrigeration circuit when installing, maintaining or servicing the unit.

### ⚠ Warning

Authorized service representatives are obligated to follow industry standard safety procedures, including, but not limited to, local/national regulations for disconnection / lock out / tag out procedures for all utilities including electric, gas, water and steam.

### ⚠ Warning

Do not store or use gasoline or other flammable vapors or liquids inside or within the vicinity of this or any other appliance. Never use flammable oil soaked cloths or combustible cleaning solutions, for cleaning..

### ⚠ Warning

This product contains chemicals known to the State of California to cause cancer and/or birth defects or other reproductive harm. Operation, installation, and servicing of this product could expose you to airborne particles of glasswool or ceramic fibers, crystalline silica, and/or carbon monoxide. Inhalation of airborne particles of glasswool or ceramic fibers is known to the State of California to cause cancer. Inhalation of carbon monoxide is known to the State of California to cause birth defects or other reproductive harm.

### ⚠ Warning

Do not use electrical appliances or accessories other than those supplied by the manufacturer.

### ⚠ Warning

Use caution when handling metal surface edges of all equipment.

### ⚠ Warning

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision concerning use of the appliance by a person responsible for their safety. Do not allow children to play with this appliance.

### ⚠ Caution

Use caution handling, moving and use of the R290 refrigerators to avoid either damaging the refrigerant tubing or increasing the risk of a leak. Components shall be replaced with like components. Servicing shall be done by a factory authorized service personnel to minimize the risk of possible ignition due to incorrect parts or improper service.

### Notice

Proper installation, care and maintenance are essential for maximum performance and trouble-free operation of your equipment. Visit our website [www.mtwkitchencare.com](http://www.mtwkitchencare.com) for manual updates, translations, or contact information for service agents in your area.

### Notice

Climatic class 4 is defined as ambient conditions of 30°C and 55% relative humidity, according to ISO 23953-2.

### Notice

These appliances are intended to be used for commercial applications, for example in kitchens of restaurants, canteens, hospitals and in commercial enterprises such as bakeries, butcheries, etc., but not for continuous mass production of food.

### Notice

This product utilizes Ecomate blowing agent methyl formate

# Table of Contents

---

## Section 1

### General Information

Model Numbers .....	4
Serial Number Information.....	4
Warranty Information.....	4
Regulatory Certifications .....	4
Standard Models.....	4

## Section 2

### Installation

Location .....	5
Clearance Requirements.....	5
Weight Of Equipment .....	6
Dimensions .....	6
Capacity .....	6
Electrical Service .....	6
Drain Connections .....	7
Leg & Caster Installation.....	7
Refrigeration .....	7

## Section 3

### Operation

Loading NLFACP Series.....	8
Lid Operation .....	8
Evaporator Fan Operation.....	8
Control .....	9
At Start Up.....	9
Defrost .....	9
ERC112 Temperature Control.....	9
Alarms .....	9
Temperature Alarm.....	10
Changing Display from Fahrenheit to Celsius on ERC112 Control.....	10

## Section 4

### Maintenance

General Cleaning .....	11
Interior Cleaning.....	12
Gaskets.....	12
Preventing Blower Coil Corrosion .....	12
Exterior Cleaning .....	12
Drain.....	12
Doors .....	13
Cleaning The Condenser Coil .....	13
Wiring Diagram .....	14

## Section 1

### General Information

---

#### Model Numbers

This manual covers the following self contained work tables:

Self Contained Free Standing Milk or Beverage Dispensers with Air Curtain
NLFACP-8
NLFACP-12
NLFACP-16

#### Serial Number Information

The serial number is on the identification plate that also includes the model number.

- The id plate on all NLFACP Milk and Beverage Coolers is on the back of the unit near the power cord.

**Always have the serial number of your unit available when calling for parts or service.**

#### Warranty Information

Visit [www.delfield.com/warranty](http://www.delfield.com/warranty) to:

- Register your product for warranty.
- Verify warranty information.
- View and download a copy of your warranty.

#### Regulatory Certifications

##### STANDARD MODELS

115Volt, 60Hertz, 1Phase models are certified by:

-  National Sanitation Foundation (NSF)
-  Underwriters Laboratories (UL)
-  Underwriters Laboratories of Canada (cUL)

## Section 2

### Installation

#### ⚠ DANGER

Installation must comply with all applicable fire and health codes in your jurisdiction.

#### ⚠ DANGER

Use appropriate safety equipment during installation and servicing.

#### ⚠ Warning

Remove all removable panels before lifting and installing.

#### ⚠ Warning

Do not damage the refrigeration circuit when installing, maintaining or servicing the unit.

#### ⚠ Caution

When adding any item verify the location of the refrigeration lines on wrapped rail units. A refrigeration leak in a rail may be irreparable or extremely difficult and costly to repair.

### Location

#### ⚠ Warning

This equipment must be positioned so that the plug is accessible unless other means for disconnection from the power supply (e.g., circuit breaker or disconnect switch) is provided.

#### ⚠ Warning

To avoid instability the installation area must be capable of supporting the combined weight of the equipment and product. Additionally the equipment must be level side to side and front to back.

#### ⚠ Warning

This equipment is intended for indoor use only. Do not install or operate this equipment in outdoor areas.

#### ⚠ Caution

Do not position the air intake vent near steam or heat exhaust of another appliance.

The location selected for the equipment must meet the following criteria. If any of these criteria are not met, select another location.

- The location MUST be level, stable and capable of

supporting the weight of the equipment.

- The location MUST be free from and clear of combustible materials.
- Equipment MUST be level both front to back and side to side.
- Position the equipment so it will not tip or slide.
- Front casters MUST be locked once positioned.
- Recommended air temperature is 50° - 100°F (10° - 38°C).
- Proper air supply for ventilation is REQUIRED AND CRITICAL for safe and efficient operation.
- Do not obstruct the flow of ventilation air. Make sure the air vents of the equipment are not blocked.
- Do not install the equipment directly over a drain. Steam rising up out of the drain will adversely affect operation, air circulation, and damage electrical / electronic components.

### Clearance Requirements

#### ⚠ DANGER

Minimum clearance requirements are the same for noncombustible locations as for combustible locations. The flooring under the appliance must be made of a noncombustible material.

#### ⚠ DANGER

Risk of fire/shock. All minimum clearances must be maintained. Do not obstruct vents or openings.

Back / Sides	0.00" (0mm)
--------------	-------------

- Keep the vents clean and free of obstruction.
- Casters or legs must be used and not removed.

### Weight Of Equipment

Model	Weight
<b>Self Contained Free Standing Milk or Beverage Dispensers with Air Curtain</b>	
NLFACP-8	401lbs (182kg)
NLFACP-12	491lbs (223kg)
NLFACP-16	583lbs (264kg)

**DIMENSIONS**

Model	Length	Depth	Height
<b>Self Contained Free Standing Milk or Beverage Dispensers with Air Curtain</b>			
NLFACP-8	40.04" (102cm)		
NLFACP-12	54.04" (137cm)	32" (81cm)	42.50" (108cm)
NLFACP-16	68.04" (173cm)		

**Capacity**

	17.75" (45cm)	24.75" (63cm)	31.75" (81cm)
<b>Shelf Max Load</b>	99lbs (45kg)	124lbs (56kg)	140lbs (64kg)

Model	# Of Doors			Base Volume FT <sup>3</sup>	# of 13"x13"x11" cases
	17.75" (45cm)	24.75" (63cm)	31.75" (81cm)		
<b>Self Contained Free Standing Milk or Beverage Dispensers with Air Curtain</b>					
NLFACP-8	2			9.36	8
NLFACP-12		2		13.81	12
NLFACP-16			2	16.52	16

**Electrical Service****DANGER**

Check all wiring connections, including factory terminals, before operation. Connections can become loose during shipment and installation.

**Warning**

This appliance must be grounded and all field wiring must conform to all applicable local and national codes. Refer to rating plate for proper voltage. It is the responsibility of the end user to provide the disconnect means to satisfy the authority having jurisdiction.

- Plug units with R290 refrigerant into a receptacle that is a minimum of 14" (36cm) above the floor.
- All electrical work, including wire routing and grounding, must conform to local, state and national electrical codes.
- The equipment must be grounded.
- A separate fuse/circuit breaker must be provided for each unit.
- If optional electrical receptacles are mounted in the unit's backsplash, they must be wired independently from the existing unit wiring.
- The maximum allowable voltage variation is  $\pm 10\%$  of the rated voltage at equipment start-up (when the electrical load is highest).
- Check all green ground screws, cables and wire connections to verify they are tight before start-up.

**Ground Fault Circuit Interrupter**

Ground Fault Circuit Interrupter (GFCI/GFI) protection is a system that shuts down the electric circuit (opens it) when it senses an unexpected loss of power, presumably to ground. Welbilt does not recommend the use of GFCI/GFI circuit protection to energize our equipment. If code requires the use of a GFCI/GFI then you must follow the local code. The circuit must be dedicated, sized properly and there must be a panel GFCI/GFI breaker. We do not recommend the use of GFCI/GFI outlets to energize our equipment as they are known for more intermittent nuisance trips than panel breakers.

**Notice**

These appliances will operate within the marked rated voltage range without adjustment.

**Notice**

This symbol indicates the location of the equipotential bonding conductor connection.

**Leg & Caster Installation****Leveling**

After the cabinet has been placed in the desired location, cabinets with legs must be leveled. Level units from front to back and from side to side. Leveling will insure proper door operation and removal of condensate. Cabinets with casters must have the caster brake set so the cabinet cannot move.

**Stabilizing**

It is very important that all legs are properly adjusted to keep the cabinet level, evenly distribute the weight and to make sure the unit will not rock, lean or be unstable.

**Refrigeration**

Model	Amps	H.P.	NEMA Plug	Voltage, Hertz, Phase
<b>Self Contained Free Standing Milk or Beverage Dispensers with Air Curtain</b>				
NLFACP-8	5.2	.35	5-15P	115, 60, 1
NLFACP-12	5.2	.35		
NLFACP-16	5.2	.35		

Model	BTU System Capacity	Heat of Rejection	Charge
<b>Self Contained Free Standing Milk or Beverage Dispensers with Air Curtain</b>			<b>R290</b>
NLFACP-8	3110	2878	150g
NLFACP-12	3110	2501	150g
NLFACP-16	3110	2300	150g

**Drain Connections**

Self-contained work tables come standard with a condensate evaporator. If the condensate evaporator fails, the unit's drain must have an outlet to an appropriate drainage area or container.

If the optional drain is ordered, a refrigerated rail can have a 1" (25mm) drain. The drain will be stubbed to the bottom of the machine compartment. Either run drain to a floor drain or add a valve to the base of the machine compartment and drain the rail to a container.

**⚠ Warning**

Moisture collecting from improper drainage can create a slippery surface on the floor and a hazard to employees. It is the owner's responsibility to provide a container or outlet for drainage.



## Section 3

### Operation

#### ⚠ DANGER

The on-site supervisor is responsible for ensuring that operators are made aware of the inherent dangers of operating this equipment.

#### ⚠ DANGER

Do not operate any appliance with a damaged cord or plug. All repairs must be performed by a qualified service company.

#### ⚠ DANGER

Never stand on the unit! They are not designed to hold the weight of an adult, and may collapse or tip if misused in this manner.

#### ⚠ DANGER

Keep power cord AWAY from HEATED surfaces. DO NOT immerse power cord in water. DO NOT let power cord hang over edge of table or counter.

#### ⚠ Warning

Do not contact moving parts.

#### ⚠ Warning

The operator of this equipment is solely responsible for ensuring safe holding temperature levels for all food items. Failure to do so could result in unsafe food products for customers.

#### ⚠ Warning

Do not use electrical appliances or accessories other than those supplied by the manufacturer.

#### ⚠ Warning

All covers and access panels must be in place and properly secured, before operating this equipment.

#### ⚠ Warning

Do not block the supply and return air grills or the air space around the air grills. Keep plastic wrappings, paper, labels, etc. from being airborne and lodging in the grills. Failure to keep the air grills clear will result in unsatisfactory operation of the system.

#### ⚠ Warning

Damp or wet hands may stick to cold surfaces.

#### ⚠ Caution

Overloading the storage area, restricting the air flow, and continuous opening and closing of the doors and drawers will hamper the units ability to maintain operational temperature.

#### ⚠ Caution

Do not throw items into the display case or storage area. Failure to heed this recommendation could result in damage to the interior of the cabinet or to the blower coil.

### Loading NLFACP Series

These cabinets are designed to dispense 13" x 13" x 11" high (maximum dimensions) dairy cases. Model NLFACP-8 holds eight cases; four on the bottom and four on the top. Model NLFACP-12 holds twelve cases; six on the bottom and six on the top. Model NLFACP-16 holds sixteen cases; eight on the bottom and eight on the top.

Milk cases are loaded through the wide opening in the top and front of the unit. Fold the hinged lids up and back and rest them on the top. The cabinet interior has self-locating guides installed to make loading easy.

### Loading Clearances

Milk crates and product must leave 2" of air flow space near the fan(s) to prevent product from freezing, even with a setpoint above freezing temperatures. Incorrect stacking of crates may cause reduced airflow, resulting in freezing product.



Correct location: 2" gap between crates and wall allowing proper air flow around crates.



Incorrect location: Crates are too close to the wall and covering the fan, restricting air flow.

## Lid Operation

Operating the unit for extended periods of time with the lid open may result in product temperature change. For best operation, leave the lid open no longer than 2 hours during peak usage.

## Evaporator Fan Operation

Depending on the units requirements, units may have evaporator fans that run continually or cycle on and off when power is applied. If you have a unit that you notice the fan is cycling, please see the operations sequence below.

When the refrigerator is initially powered up or immediately following a power outage the unit will begin cooling after a 3-6 minute delay. During normal operation the evaporator fan pulses independently of the compressor as dictated by the controller as follows:

1. During the cooling mode, compressor and evaporator fan run simultaneously.
2. During the compressor off mode, evaporator fan pulses three minutes on and three minutes off.
3. During an actual defrost event other than the off-cycle defrost, compressor stays off but the evaporator fan runs continuously.

Cooling Cycle		Defrost Cycle
Compressor On	Compressor Off	Compressor Off
Evaporator Fan On	Evap Fan Cycles On 3-Min, Off 3-Min	Evaporator Fan On

## CONTROLS

### At Start Up

1. At initial start-up or anytime power is disconnected, then reconnected to the unit, the control will go into defrost mode.
2. The control will enter a DEFROST mode and the display will read dEF. The compressor and condenser fan as well as the evaporator fan will remain off until this initial defrost is complete. This initial defrost cycle may take up to 35 minutes to complete.
3. The display will continue to read dEF for an additional 30 minutes while the cooling cycle cools the box to the set temperature.
4. Then the digital thermostat will display box temperature. Normal operation setpoint is 36°F.
5. The temperature control will cycle the compressor, evaporator fan motor and condenser fan motor to maintain box temperature at the control setting. For more information see Evaporator Fan Operation on page 9.

### Defrost

The temperature control also monitors the evaporator temperature and will turn off the compressor and condenser fan motor when needed to allow accumulated frost on the evaporator to clear. During this defrost cycle, the digital temperature display will read dEF. After the defrost cycle is complete, the temperature control will return to a normal cooling cycle, but the display will continue to read dEF until the evaporator returns to normal cooling temperatures (up to 30 minutes).

The electronic temperature controller monitors evaporator temperature and compressor run time to determine the proper time for a positive defrost cycle. A defrost cycle can occur as often as every 2 hours under extremely heavy usage. It can last a minimum of 2 minutes. When the controller enters the defrost mode the compressor is shut off and will remain off until the evaporator coil temperature exceeds:

- 41°F (5°C) or the controller reaches a time limit of 100 minutes on a refrigerated unit.

## ERC112 TEMPERATURE CONTROL

Status	Displayed	Comments
Normal (°C)	Temp. [°C]	Unit depends on setting (parameters in control)
Normal (°F)	Temp. [°F]	
Show set-point	Temp.	
Set to Defrost	dEF / Temp	Depends on setting (parameters in control or as chosen by upper left button)
Sensor 1 defect	E01	X Air sensor
Sensor 2 defect	E02	X Coil sensor
Sensor 3 defect	E03	X Open
Sensor 4 defect	E04	X Open
High temperature alarm	Hi	Automatically switching at 2 sec rate
Low temperature alarm	Lo	
Line voltage too high, above 140 volts	uHi	
Line voltage too low, below 96 volts	uLi	X
Control calls for cooling for more than 24 hours straight	LEA	X Time includes defrost. Error will go away if the control cycles off the compressor or if the power is shut off. If error is on a cold pan it could be related to a high ambient temperature or not shutting the rail off nightly.

All alarms sound for approximately 10 seconds and then

are silent for 50 seconds. It will do that for 15 cycles and then remain silent. The alarm code will still be present on the display until the fault clears.

#### Press upper or lower right button.

- Display show actual set-point (blinking).
  - If buttons untouched for 3 seconds returns to normal.
- Increase set-point by pressing upper button. Max value depends on parameters in control.
- Decrease set-point by pressing lower button. Min value depends on parameters in control.
  - If buttons untouched for 3 seconds returns to normal and stores new set-point.

#### Press upper left button for 5 seconds.

- Start defrost.

#### Press lower left button for 5 seconds.

- Unit goes into stand-by mode.
  - The display will read Off, then a period.
- Press the lower left button again for 5 seconds.
  - The display will read On.
  - The unit will then start up in the defrost mode, and display will read dEF.

#### Temperature Alarm

The alarm will sound and flash HI or LO 90 minutes after the unit has reached its alarm temperature point or after any power interruption if the temperature is above or below the alarm set points.

- The high refrigerator temperature point is 50°F (10°C).
- The low refrigerator temperature point is 25°F (-4°C).

#### CHANGING DISPLAY FROM FAHRENHEIT TO CELSIUS ON ERC112 CONTROL

- Simultaneously hold the up and down arrows for 5 seconds to access menu for password protected parameters.



- Screen should temporarily flash **PAS** and then move to a numeric screen.



- Scroll to **187** using the up/down arrows and push the stand-by button (lower left button) to enter.



- Scroll to **dis** using the up/down arrows and push the stand-by button (lower left button) to enter into the display menu.



- Scroll to **CFu** using the up/down arrows and push the stand-by button (lower left button) to enter the display unit menu.



6.  $-\text{F}$  should be displayed indicating Fahrenheit. Use the down arrow to change it to  $-\text{C}$  for Celsius and hit the stand-by button (lower left button) to enter the change.



7. Push the defrost button (upper left button) to move out of the display unit menu.



8. Push the defrost button (upper left button) to move out of the display menu and back to the normal display.



9. For steps 7 and 8, display will return back to normal display after 30 seconds of inactivity.

## Section 4

### Maintenance

#### ⚠ DANGER

It is the responsibility of the equipment owner to perform a Personal Protective Equipment Hazard Assessment to ensure adequate protection during maintenance procedures.

#### ⚠ DANGER

Failure to disconnect the power at the main power supply disconnect could result in serious injury or death. The power switch DOES NOT disconnect all incoming power.

#### ⚠ DANGER

Disconnect electric power at the main power disconnect for all equipment being serviced. Observe correct polarity of incoming line voltage. Incorrect polarity can lead to erratic operation.

#### ⚠ Warning

When cleaning interior and exterior of unit, care should be taken to avoid the front power switch and the rear power cord. Keep water and/or cleaning solutions away from these parts.

#### ⚠ Warning

Never use sharp objects or tools to remove ice or frost. Do not use mechanical devices or other means to accelerate the defrosting process.

#### ⚠ Caution

Over shelves and other items mounted to the top of the counters should never be installed in the field due to the potential damage to the refrigeration system.

#### ⚠ Caution

Maintenance and servicing work other than cleaning as described in this manual must be done by an authorized service personnel.

### General Cleaning

#### ⚠ Warning

When using cleaning fluids or chemicals, rubber gloves and eye protection (and/or face shield) must be worn.

#### Notice

Never use a high-pressure water jet for cleaning or hose down or flood interior or exterior of units with water. Do not use power cleaning equipment, steel wool, scrapers or wire brushes on stainless steel or painted surfaces.

You are responsible for maintaining the equipment in accordance with the instructions in this manual. Maintenance procedures are not covered by the warranty.

Maintenance	Daily	Weekly	Monthly	After Prolonged Shutdown	At Start-Up
Interior	X			X	X
Gasket	X			X	X
Exterior	X			X	X
Drain		X		X	X
Drawers/Door		X		X	X
Condenser Coil			X	X	X

## Interior Cleaning

The interior can be cleaned using soap and warm water. If this isn't sufficient, try ammonia and water or a nonabrasive liquid cleaner.

### GASKETS

Gaskets require regular cleaning to prevent mold and mildew build up and also to retain the elasticity of the gasket. Clean them with water and mild soap (not citrus based). Avoid full strength cleaning products on gaskets as this can cause them to become brittle and crack. Never use sharp tools or knives to scrape or clean the gasket. Gaskets can be easily replaced and do not require the use of tools or an authorized service person. The gaskets are dart style and can be pulled out of the groove in the door. Place gasket in warm water to make the material more pliable for installation. Dry and press into place.

### PREVENTING BLOWER COIL CORROSION

To help prevent corrosion of the blower coil, store all acidic items, such as pickles and tomatoes, in seal-able containers. Immediately wipe up all spills.

## Exterior Cleaning

### Notice

Never use an acid based cleaning solution on exterior panels! Many food products have an acidic content, which can deteriorate the finish. Be sure to clean the stainless steel surfaces of ALL food products.

Clean the area around the unit as often as necessary to maintain cleanliness and efficient operation.

Wipe surfaces with a damp cloth rinsed in water to remove dust and dirt from the outside of the unit. Always rub with the "grain" of the stainless steel to avoid marring the finish. If a greasy residue persists, use a damp cloth rinsed in a mild dish soap and water solution. Wipe dry with a clean, soft cloth.

Never use steel wool or abrasive pads for cleaning. Never use chlorinated, citrus based or abrasive cleaners.

Stainless steel exterior panels have a clear coating that is stain resistant and easy to clean. Products containing abrasives will damage the coating and scratch the panels. Daily cleaning may be followed by an application of stainless steel cleaner which will eliminate water spotting and fingerprints. Early signs of stainless steel breakdown are small pits and cracks. If this has begun, clean thoroughly and start to apply stainless steel cleaners in attempt to restore the steel.

Wipe casters with a damp cloth to prevent corrosion.

### DRAIN

Drains can become loose or disconnected during normal use. Be sure all drain lines are free of obstructions.



## Doors

Over time and with heavy-use doors, the hinges may become loose. If this happens, tighten the screws that mount the hinge brackets to the frame of the unit. Loose or sagging doors can cause the hinges to pull out of the frame, which may damage both the doors and the hinges. In some cases this may require qualified service agents or maintenance personnel to perform repairs.


## Cleaning The Condenser Coil

In order to maintain proper refrigeration performance, the condenser fins must be cleaned of dust, dirt and grease regularly. It is recommended that this be done monthly. If conditions are such that the condenser is totally blocked in a month, the frequency of cleaning should be increased. Clean the condenser with a vacuum cleaner or stiff brush. If extremely dirty, a commercially available condenser cleaner may be required.

Failure to maintain a clean condenser coil can initially cause high temperatures and excessive run times. Continuous operation with a dirty or clogged condenser coil can result in compressor failure. Neglecting the condenser coil cleaning procedures will void any warranties associated with the compressor and cost to replace the compressor.

## Wiring Diagram

000-SCH-016V





DELFIELD  
980 SOUTH ISABELLA ROAD, MOUNT PLEASANT, MI 48858  
800-733-8821  
WWW.DELFIELD.COM



Welbilt offers fully-integrated kitchen systems and our products are backed by KitchenCare® aftermarket parts and service. Welbilt's portfolio of award-winning brands includes **Cleveland™**, **Convotherm®**, **Crem®**, **Delfield®**, **fitkitchen®**, **Frymaster®**, **Garland®**, **Kolpak®**, **Lincoln®**, **Manitowoc®**, **Merco®**, **Merrychef®** and **Multiplex®**.

*Bringing innovation to the table • [welbilt.com](http://welbilt.com)*